


American Standard

**TIME SQUARE™  
DECK-MOUNT BATH FILLER**

**Installation  
Instructions**

**7184.900  
7184.901**





Certified to comply with ANSI A112.18.1M  
M965466 Rev. 1.2

*Thank you for selecting American-Standard...the benchmark of fine quality for over 100 years.*


*To ensure that your installation proceeds smoothly—please read these instructions carefully before you begin.*

**Required Tools**




**1 SPOUT ASSEMBLY** **CAUTION** Turn off hot and cold water supplies before beginning.

- Insert SPOUT SHANK (1) through center hole of MOUNTING LEDGE. Make sure that the RUBBER RING (2) is properly seated in RECESS at base of SPOUT (3).
- Assemble RUBBER WASHER (4) and BRASS WASHER (5) onto SHANK (1). From underside of ledge secure SPOUT (3) into position with LOCKNUT (6).



**2 PREPARE TUBE AND TEE ASSEMBLY**



- Prepare TUBE and TEE ASSEMBLY (1) to fit center to center VALVE (2) location (between 6-1/2" and 12"). If necessary, cut and/or bend TUBING carefully. Make sure tube bend is close to the TEE (1) so that it will not effect the compression joint at the VALVE CONNECTION.
- Remove COUPLING NUT (3) and FERRULE (4) from each VALVE (2) and slide onto TUBING (5).



**NOTE** VALVE inlet is 3/4-inch NPT male connector.


### 3 VALVE ASSEMBLY

- Install LOCKNUTS (1) and RUBBER WASHERS (3) onto valve shanks.
- Push TUBING (4) ends into VALVE (5) side outlets. Insert VALVES (5) into mounting holes from underside of ledge.
- Press TEE (6) onto SPOUT SHANK (7) making certain that the O-RING (8) is properly seated on SHANK (7). Push COUPLING (9 or 9a) into TEE (6) and attach to SPOUT SHANK (7) and tighten. **Note: For product with Hand Shower, COUPLING (9) is tightened using a 10mm (3/8") Hex Wrench.**
- Place RUBBER RING (11) into DECK ADAPTERS (10) and thread onto valves until snug against internal stop.
- Tighten LOCKNUT (1) to secure VALVE (5) position.
- Slide FERRULE (13) and COUPLING NUT (14) to outlet of VALVE (5) and tighten COUPLING NUT (14) firmly.
- Connect HOT water supply to inlet of left VALVE and COLD water supply to inlet of right VALVE using appropriate connector.



### 4 INSTALL HANDLES


- Turn VALVE to OFF position.
- Push ADAPTER (1) on VALVE STEM (2), so that the hole of the ADAPTER (1) without a spline is facing up. **Fig. A.** Tighten STEM SCREW (3) to secure ADAPTER (1).
- Align **male teeth** on DECK ADAPTER (5) to **female teeth** in LEVER HANDLE ASSEMBLY (4). Push LEVER HANDLE ASSEMBLY (4) onto DECK ADAPTER (5) flush against mounting surface.
- Tighten SET SCREW (6) with HEX WRENCH supplied to secure LEVER HANDLE ASSEMBLY (4). **View A.**



## 5 HANDSHOWER INSTALLATION (Model 7184.901 series only)

- Drop SPRAY ESCUTCHEON (1) through the fourth hole of the tub ledge (12" max from SPOUT center) with SPRAY ESCUTCHEON (1) directed towards tub center. Be sure RUBBER RING (2) is properly seated in ESCUTCHEON (1). Install RUBBER WASHER (3) BRASS WASHER (4) and LOCKNUT from underside of ledge.
- Secure SPRAY ESCUTCHEON (1) by tightening LOCKNUT.
- Add SEAL WASHER (5) and connect HOSE (10) to outlet nipple at the bottom of COUPLING (7). Tighten firmly.
- Slip SHOWER HOSE (8) with COUPLING NUT through SPRAY ESCUTCHEON (1). Install SEAL (9) and connect both HOSES (8) and (10), Connect HAND SHOWER (11) to SPRAY HOSE (8).

**NOTE** When not in use, HANDSHOWER should be seated in the HOLDER.



## 6 TEST INSTALLED FAUCET

- Turn VALVES "off" and attach handles.
- With handles in "off" position, turn on water supplies and check all connections for leaks.
- Operate both handles and flush water lines thoroughly.
- Check SPOUT mounting for leaks.


### CAUTION

The flow rate of this Tub Filler exceeds 20 gallons/minute at higher water pressure. Do not fill bathtub unattended.

- Lift HANDSHOWER from HOLDER, direct spray into tub, lift TRANSFER KNOB to check HANDSHOWER and HOSES for leaks.
- Turn handles "off."


## 7 Before the bathroom is completely finished, you may want to remove spout, handshower, and handles to avoid damage during construction.

- To remove handles, reverse steps in section 4.
- To remove SPOUT (1), proceed as follows:
  - Unthread LIFT ROD KNOB (2) and remove.
  - Remove PLUG BUTTON (3) and remove SET SCREW (4) using 4mm hex wrench supplied.
  - Lift SPOUT (1) off SHANK (5) carefully and remove RUBBER RING (6).
  - Unthread SHANK SLEEVE (7) and remove from SHANK (5).
  - Reverse sequence to re-install SPOUT (1). Be sure RUBBER RING (6) is properly seated in its recess at the base of the SPOUT (1). Make certain SET SCREW (4) is properly aligned and tight so that SPOUT (1) is locked in place.



## 8 SERVICE

- To change direction of handle rotation, proceed as follows:
  - Turn valve to OFF position.
  - Loosen SET SCREW (1) and pull off HANDLE ASSEMBLY (2).
  - Loosen HANDLE SCREW (3) and pull off HANDLE ADAPTER (4).
  - Remove SPRING CLIP (5).
  - Lift STOP WASHER (6), turn 90° and replace.
  - Replace SPRING CLIP (5).
  - Refer to step four for HANDLE ASSEMBLY (2) instructions.
- If spout drips, operate handles several times from OFF to ON position. Do not force - handles turn only 90°.



## 9 CARE INSTRUCTIONS:

**DO: SIMPLY RINSE THE PRODUCT CLEAN WITH CLEAR WATER. DRY WITH A SOFT COTTON FLANNEL CLOTH.**

**DO NOT: DO NOT CLEAN THE PRODUCT WITH SOAPS, ACID, POLISH, ABRASIVES, HARSH CLEANERS, OR A CLOTH WITH A COARSE SURFACE.**

**M964423-YYY0A**  
SPOUT KIT (7184.900)

**M964437-YYY0A**  
SPOUT KIT (7184.901)

**M917161-0070A**  
SET SCREW

**M962849-0070A**  
STREAM STRAIGHTENER

**A912629-0070A**  
RUBBER RING

**M962575-YYY0A**  
TRANSFER LIFT KNOB

Replace the "YYY" with appropriate finish code

CHROME	002
SATIN NICKEL	295

**M952454-0070A**  
TRANSFER ROD ASSEMBLY

**030278-0070A**  
TRANSFER SEAL KIT

**M918075-0070A**  
SET SCREW

**M964416-YYY0A**  
LEVER HANDLE ASSEMBLY

**030275-0070A**  
SHANK SLEEVE KIT

**M964417-0070A**  
DECK ADAPTER KIT

**M961634-0070A**  
VALVE MTG. KIT

**030274-0070A**  
SHANK MOUNTING KIT

**M950332-YYY0A**  
HAND SHOWER

**M964421-YYY0A**  
HAND SHOWER HOLDER

**918555-0070A**  
HANDLE SCREW

**918049-0070A**  
HANDLE ADAPTER

**994053-0070A**  
CARTRIDGE

**012668-0070A**  
SHANK KIT

**028679-0070A**  
TUBE & TEE ASSEMBLY

**028699-0070A**  
COUPLING (FOR TRANSFER)

**028698-0070A**  
COUPLING (LESS SPRAY)

**012078-0070A**  
VALVE COUPLING KIT

**A952849-0070A**  
CHECK VALVE

**028667-0020A**  
HAND SHOWER HOSE

**051343-0070A**  
HOSE KIT



**HOT LINE FOR HELP**

For toll-free information and answers to your questions, call:  
1-800-442-1902  
Weekdays 8:00 a.m. to 6:00 p.m. EST  
IN CANADA 1-800-387-0369 (TORONTO 1-905-306-1093)  
Weekdays 8:00 a.m. to 7:00 p.m. EST  
IN MEXICO 01-800-639-1200