



Buy it for looks. Buy it for life.®

Illustrated Parts

■ Order by Part Number

Two-Handle Laundry Faucet


MODEL	HANDLE	FINISH
4872	Chrome Knob	Chrome
4873	Acrylic Knob	Chrome

Handle Insert Kit

103058 HOT
103059 COLD



Handle Screw
12648




Cartridge Nut
14986



Replacement Cartridge
1224




Escutcheon
13567



Retaining Ring &
Spout O-Ring
101879

Spout Nut
14939



Spout Assembly
91992

Garden Hose
Adapter
92018



Hardware Package
13678

