

14003519-001


ADD-A-GAUGE KIT

TYPICAL APPLICATIONS

- To read supply (main) air pressure
- To read branch line pressure during calibration
- To aid in troubleshooting pneumatic systems

INSTALLATION

Install gauge in either copper or plastic tubing using fittings provided.
The best location in a branchline is close to the device being operated.



Honeywell